


Legende:

- | | |
|---|-------|
| 1 Kaltwasser/ Cold water | R 1½" |
| 2 Warmwasser/ Hot water | R 1½" |
| 3 Vorlauf Heizung/ Flow heating | R 1" |
| 4 Rücklauf Heizung/ Return heating | R 1" |
| 5 Muffe für Thermostat/ Coupling for thermostat | Rp ½" |
| 6 Muffe für Thermometer/ Coupling for thermometer | Rp ½" |
| 7 Zirkulation/ Circulation | Rp 1" |
| 8 Handloch-Flansch/ Hand-hole flange | ø 270 |
| 9 Handloch-Flansch/ Hand-hole flange | ø 180 |



1:15
 Hoval CombiVal CSR (1000)
 4215327 Version 00
 Stand: 21.08.2018